




AMERICAN CAR CRAFT INSTRUCTION

Pontiac G8 Cap Cover 3Pc Kit (fits Factory Shroud)

PART#223008



PARTS INCLUDED:

2-3/4" Chrome Cap Covers

1-Stainless Trim Ring

1-Adhesive Promoter Pack

1. Thoroughly scrub clean the tops of the two factory caps with alcohol to remove dirt then swipe them once with the adhesive promoter provided.
2. Also clean the inner area of the power steering reservoir and swipe it with the adhesive promoter as well.
3. You will notice the each of the two caps contain an attachment cookie located under the two caps. Separate the cookie halves and place them to the top of the factory caps you just prepped.

4. You have been provided with a stainless trim ring. Peel the red release liner from the back of the ring and set into place around the power steering reservoir neck directly onto the engine shroud.
5. With the trim ring in place simply set the new decorative covers onto the two factory caps.

If any questions occur during installation please contact American Car Craft @

727-861-1500

Thank you and enjoy your purchase!

AMERICAN CAR CRAFT

18924 SAKERA ROAD-HUDSON FLORIDA 34667

Phone # 727-861-1500 Fax # 727-861-1520

www.americancarcraft.com